

APPROVED BY EASA UNDER APPROVAL NUMBER 10038169

8.36 PASSENGER RESTRAINT HARNESS

8.36.1 GENERAL INFORMATION

This supplement shall be inserted in the Flight Manual, in Section 8: 'Supplements' with the revisions record sheet amended accordingly.

Information contained herein supplements, or in the case of conflict, supersedes that contained in the basic Flight Manual. For Limitations, Procedures, and Performance Data not contained in this supplement, consult the basic Hot Air Balloon Flight Manual.

Issue 2 of this supplement consists of two pages.

Supplement 7.36 (two pages) to Maintenance Manual Issue 10 is required to ensure continued airworthiness.

8.36.2 LIMITATIONS

No change.

8.36.3 EMERGENCY PROCEDURES

No change.

8.36.4 NORMAL PROCEDURES

8.36.4.12 PASSENGER RESTRAINT HARNESS

The passenger restraint harness consists of a waist belt, which is fastened with an aircraft style seat belt buckle, and a floor strap which is anchored to the base of the basket. The free end of the floor strap is fitted with a karabiner which is clipped onto a D-ring on the waist belt.

The waist belt is fitted to each passenger prior to the flight. Before landing the passenger can clip waist belt to the floor strap (on the instructions of the pilot).

Note: The restraint harness is designed to give added security in the landing phase of the flight. It is not a substitute for adopting a good landing position and using internal handles.

8.36.5 WEIGHT CALCULATIONS

No change.

8.36.6 BALLOON AND SYSTEMS DESCRIPTION

No change.

8.36.7 BALLOON MAINTENANCE, HANDLING AND CARE

No change.

8.36.9 EQUIPMENT LIST

No change.